



**EU
Code List
V9.3**

TV Code List	
ACCENT	2541
1701,1361,1181,0081	
ACCUPHASE	1361
ACER	1321
ACOUSTIC SOLUTIONS	6801
6791,2121	
ACTION	1801
1111,0911,0081,0021	
ACURA	1181,0081
ADCOM	1291
ADLER	8191,4101
ADMIRAL	2651
2191,1811,1721,1021,0371	
0081,0071,0021	
ADVENT	6951
ADVENTURA	0141
ADYSON	2221
1861,1851,1111,0951,0021	
AEA	1361,1181,0141
AEG	1731,1661,0141
AGASHI	1861,1851,1811
AGATH	6961,1761
AGB	0951
AGEF	1021
AIKO	2541,1861,1811,1701
1361,1331,0151	
AIM	2541,1821,1771,1731
1361,1181	
AIRIS	7721,7251,7241,6971
4381	
AIWA	3391
3211,6741,2071,6931	
AKAI	4371,2541,1871,1861,1811
1771,1761,1731,1701,1651	
1331,1181,1111,1091,1081	
1061,0951,0551,0461,0441	
0321,0041	
AKASHI	1701
AKIBA	2541,1361,1181,1081
AKITO	2541,1361,1181
AKURA	4381,2541,1811,1701
1361,1181,1081,0081,0041	
0021	
ALARON	1851
ALBA	2541,2091,1871,1851
1701,1181,1091,1081,1061	
0951,0661,0411,0071,0041	
ALBIRAL	0671
ALDEN	7261
ALFA	0021
ALIEN	2541,1181
ALLORGAN	1861
1151,0951,0811	
ALLSTAR	2541
1361,1181,0021	
ALLVIEW	7141
ALPHA	7271,6541,4101
ALPHA DIGITAL	7741,7731
ALPHATRONICS	7281
ALTEK	6981
ALTUS	4171
AMBASSADOR	2261,0141
AMERICAN HIGH	1801
AMITECH	6991
AMPLIVISION	1861
0951,0411	
AMSTRAD	2541
1811,1701,1361,1181,1101	
0741,0461,0291,0081	
ANAM NATIONAL	2541
1711,1701,1361,1181	
ANDERSSON	1661
ANGA	2261,0141
ANGLO	1811,1701,0081
ANITECH	2541
2221,1811,1701,1361,1201	
1111,1081,0351	
ANSONIC	2541
1701,1361,1321,1231,1201	
1181,0411,0081,0071	
ANTARION	6401
AOC	2001,7921,1111,0021
APPLE TV	8101
AR SYSTEM	2241
1361,1181,0711	
ARC EN CIEL	1271
1241,1211,1071,0911,0851	
0841	
ARCAM	1861,1851,1241,0951
ARCELIK	4171
ARCON	1661
ARCTIC	4171
ARDEM	2541,1361,1181,0041
ARENA	2541,1871
ARIELLI	4111,4101
ARISTONA	2541
1361,1321,1181,1141,0021	
ARSTIL	4171
ART TECH	0021
ARTHUR-MARTIN	0241
0181,0071	

TV Code List	
ASA	2191,2181,1441,1021
0511,0501,0341,0071	
ASBERG	2541
1361,1201,1181,0591,0351	
0021	
ASORA	1701,0081
ASTON	2011
ASTRA	2541,1361,1181,0081
ASUKA	1861,1851,1811,1081
0951	
ATASHII	2601
ATD	1821
ATEC	7001
ATLANTIC	2541
1851,1511,1361,1181,0811	
0021	
ATORI	1701,0081
ATORO	0081
AUCHAN	0241,0181,0071
AUDIOSONIC	2541
1861,1811,1701,1651,1591	
1361,1231,1211,1081,0951	
0411,0041	
AUDIOTON	1861
1811,0951,0411,0081	
AUDIOVOX	0021
AUDIOWORLD	1821
AUMARK	1801
AUTOVOX	2541
2191,1861,1351,1181,1151	
1021,0991,0951,0811	
AVOL	1791
AVTEX	6771
AWA	2441,1861,1811,1731
1701,1171,1131	
AXEN	7291
AXION	7011
AXXENT	1701
AXXON	0041
BAIRD	1861,1771,1731,1211
0821	
BANG & OLUFSEN	2351
2191,1021,1011,0801	
BARCO	0071
BASIC LINE	2541
1861,1701,1231,1181,1081	
0071	
BASTIDE	1861,0951
BAUER	1821,1811,1701,0461
BAUR	2541,1701,1361,1351
1331,1301,1281,1181,0501	
0461,0451,0151,0141	
BAZIN	1861
BBK	2421,1991,1571,1561
1551,1541	
BEAUMARK	1761
BEC	0951,0021
BECESE	1111
1061,0911,0501,0141,0021	
BEKO	4171,2541,1731,1651
1591,0891,0491,0411,0041	
BELL & HOWELL	0021
BELSON	1831
BELSTAR	2541,1181
BENCHMARK-BEAUMARK	1801
1111,0081,0021	
BENQ	2001
BEON	2541,1361,1181,0591
0021	
BERLIN	4171
BEST	0411
BEST BUY	7321,7311,7301
BESTAR	2541
1361,1231,1181,0411,0181	
0021	
BESTAR-DAEWOO	1231
BEXA	2051
BIGSTON	0081
BINATONE	1861
BLACK DIAMOND	2541
1661,1361,1181	
BLACK PANTHER	1201
BLACKSTRIPE	1801
1061,0501	
BLAUBERG	2601
BLAUPUNKT	2091
1751,1331,1091,1081,0481	
0461,0451,0441,0431,0251	
BLOMBERG	4171
BLOOM	2541,1181
BLU-SENS	1761
BLUE	0001
BLUE SKY	4381
2541,1831,1591,1361,1181	
1081,0041,0021	
BOGO	4111
BOLVA	2621
BONDSTEC	1861
1701,1151,0991	
BPL	2541,1361,1181

TV Code List	
BRANDT	7901
2101,1291,1271,1251,1241	
1221,1071,0911,0851,0841	
0771,0761,0751	
BRENDSTAR	0081
BRIGHTON	7331,6431
Brimax	7171
BRINKMANN	2541
1361,1181,0591,0021	
BRIONVEGA	2541
1661,1361,1181,1021,0291	
0021	
BRIORRVEGA	2191,0021
BRITANNIA	1861,1851
BROCKWOOD	2261
1111,1061,0141	
BROKSONIC	1111,1061,0141
BROTHER	1811
BRUNS	2191,1021
BSR	1151,0181,0151,0071
BTC	1081
BUSH	2001,1871,4371,2761
2541,2231,1861,1821,1811	
1771,1701,1651,1361,1231	
1181,1161,1091,1081,1061	
0951,0661,0151,0041	
CAMERON	1481,1461,1451
CAMPLE	2261
1111,1061,0141	
CANCA	8031
CANDLE	1111
CAPEHART	1111,1061,0021
CAPSONIC	1811
CARAD	2541,1361,1181
CARENA	2541,1361,1181
CARREFOUR	2541
1361,1181,1061,0021	
CARVER	1751,0021
CASCADE	2541
1701,1361,1181	
CASIO	2541,1361,1351,1181
0071	
CATHAY	2541
1361,1181,0021	
CCE	2541,1861,1361,1181
CCJ	0471
CELCUS	1871
CELLO	2551,3471,2531
CENTURION	2641
2541,1361,1181,0021	
CENTURY	2191
1341,1021,1001,0991	
CGE	1241,1001,0991,0591
0411,0351,0211,0081,0071	
CGM	1081,0081
CHANGHONG	7191
7181,6931,6501,6481,6461	
6451,6441,1391,0001,6491	
6471	
CHIQ	7341,0001
CIE	1231,0461,0081
CIHAN	0021
CIMLINE	1701,1091,0081
CINEX	0021
CIRCUIT CITY	2261
1111,1061,0141	
CITIZEN	1801,1111,0021
CITY	1701,0081
CLAIRTON	1871
CLARIVOX	2541
1361,1201,1181,0991,0971	
0621	
CLATRONIC	2541
1861,1811,1731,1701,1361	
1201,1081,1001,0991,0951	
0411,0351,0181,0041	
CLAYTON	4221,1651,1871
CMS	1851
CMS HIGHTEC	1861
6741,3431	
COLORTYME	1801,0021
COLOSSUS	7351
COMPUTRON	0081
CONCORDE	1701,0081
CONDOR	2541
1851,1811,1701,1361,1201	
0991,0411,0071	
CONIA	2951
CONIC	1111,1061,0021
CONRAC	0651
CONRAD	2541,1361,1181
CONTEC	2541
1851,1811,1701,1361,1171	
1081,1061	
CONTEX	4111
CONTINENTAL EDISON	1271
1241,1071,0911,0851,0841	
0761,0751,0111	
COOCOA	3431
CORONADO	1111
COSMEL	2541

TV Code List	
1701,1361,1181,0081	
CRAIG	2481,0021
CROSELEY	2191
1061,1021,1001,0991,0351	
0221	
CROSSWOOD	2541,1181
CROWN	2541,1771,1741,1731
1701,1591,1181,1111,0411	
0351,0181,0041	
CRYSTAL	0021
CS ELECTRONICS	1851
CTC	0991
CTC CLATRONIC	0591
CURTIS MATHES	6261
1801,1721,1111,1061,0021	
CYBERTRON	0951
DAENYX	6931
DAEWOO	2541
1861,1821,1701,1361,1231	
1111,0951,0721,0091,0071	
0041	
DAICHI	0081
DAINICHI	1851,1081
DANSAI	2541
1861,1851,1811,1771,1701	
1361,1181,1111,1061	
DANTAX	1731
1591,0411,0041	
DATSURA	1771
DAWA	2541,1701,1361,1181
0021	
DAYTEK	1821,1811
DAYTRON	2541
1701,1361,1231,1181,1111	
0501,0081	
DCE	2541,1181
DE GRAAF	1771,0321,0071
DEC	4371
DECCA	2541,1861,1361,1181
1171,1041,0951,0651,0601	
0021	
DEITRON	1361,1231,1181
DELTON	2541,1181
DENKO	1811
DENVER	7751
7631,7621,4381,2881,2541	
1731,1361,1181,0081,0031	
DESMET	2541
1701,1361,1181,1021,0081	
0021	
DGM	2101
DIAMANT	2541,1361,1181
DIAMOND	1851
1821,1811,1701,0081	
DIGIHOME	2541,1871,1181
DIGILINE	2541,1361,1181
DIGILOGIC	2541,2381,1871
DIGIMATE	7021
DIGIQUEST	4111,1871
DIGITOR	1361,1181,0151
DIK	2541,1361,1181
DIKOM	7031
DISNEY	7041
DIXI	2541,1861,1701,1361
1181,1021,0081,0021	
DL	4371,0031
DMTECH	2541,1181,1871
DORIC	1351,0311
DSC	1991
DSE	1421,1411,1401,1391
DUAL	2891,2541,1871,1861
1701,1511,1351,1241,1181	
1081,0951,0821,0391	
DUINAMAI	2021
DUMONT	2191
1861,1441,1201,1111,1061	
1021,0951,0671,0141	
DUNAI	0071
DURABRAND	2541,1181
DUX	2541,1361,1321,1181
DVICO	2041
D-VISION	2541,1361,1181
DYNAMIC	0081
DYNATECH	2261
1111,1061,0951,0141	
DYNATRON	2541
1361,1321,1181	
DYON	2601
E-MAX	2101,1731
EATON	1801
ECCO	1821
ECG	7761,7371,7361,2101
1991	
ECR	1061
EDISON	1211,1871
EDUK	1871
ELBE	2541,1871,1861,1361
1341,1331,1311,0971,0441	
0411,0151	
ELBIT	0021
ELCIT	2191,1201,1021,0991

TV Code List	
0071	
ELECS	0021
ELECTRATUNE	1111
ELECTRIQ	3211,1871
ELECTRO	0141
ELECTRO TECH	0081
ELECTROHOME	2261
1111,1061,0141	
ELECTRONICS	1081,0991
ELEKTRONIKA	0021
ELEKTA	2541
1811,1701,1361,1181,0081	
ELEKTRA	4111
ELEKTABREGENZ	4171
ELEMENT	3591,2621,6621
ELFUNK	1871
ELG	2541,1361,1181
ELIN	2541,1851,1701,1441
1361,0501,0321	
ELIT	2541,1801,1361,1181
1111,1081,1061,0021	
ELKOS	7381,1871
ELMAN	1201,0891,0871,0671
0181	
ELTA	1851,1811,1701,0181
0081	
EMERSON	2541
1361,1111,1061,1021,0411	
0151,0141,0041	
E-MOTION	4381,2091
ENERGY SISTEM	1381,1371
ENIE	6931
EON	1801,1061
EPIC	0651

TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	TV Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	SAT / CABLE Code List	Soundbar Code List
PANAMA 1811,1691,1361 1851,1811,1701,1361,1181 0991,0951,0081 PANASHIBA 1691,0081 PANASONIC 2591 3451,2711,2541,1871 PANAVISION 1361,1181 PANAVOX 0081 PANDA 8181 PANORAMA 0081 PANORAMIC 0911 PANSOMINS 4371,0081 PATHE CINEMA 1851 1351,1341,0411,0391,0381 0181,0071 PATHE MARCONI 1271 1241,1211,1071,0911,0851 0841 PAUSA 1701,0081 PCE/PEC 2261 1801,1111,1061,0501,0141 PDP 2111 PEAQ 7471 PENNEY 1801,1111 PERDIO 1851 1361,1181,0071 PERFEKT 1361,1181,0021 PERFORMANCE 1061,0141 PHILCO 2191 1361,1181,1061,1021,0991 0591,0411,0351,0081,0001 PHILEX 0071 PHILHARMONIC 1861,0951 3801 PHILIPS 2541 3821,3811,3521,8061,2541 1181 PHOCUS 1651,0041 PHOENIX 2191 1851,1361,1181,1021,0411 0071,0021 PHONOLA 2191 1851,1361,1321,1181,1141 1191 1021,0021 PILOT 1801,1361,1181 PIONEER 3201 3561,1931,1841,1361,1211 0911,0411,0151 PLANTRON 1811 1701,1361,1181,0081,0021 PLAYSONIC 1861,1591,0041 POLAROID 3431 1871,1761,1451 POLICOM 1341 1271,1211,1201,1021,0911 0151,0071 POPPY 1701,0081 PORTLAND 1231,1111,0141 POWERPOINT 1821 PRANDONI-PRINCE 0991 0961,0331,0181,0151 PRECISION 1861,0951 PREMIER 1811,1071 PRIMA 2801,2021,7231,2601 1811,1801,1701,1111,1061 PRINCESS 1821,0081 PRINCETON 1871 PRINZ 1351,0151 PROELCO 0021 PROFEX 1701 0351,0181,0151,0081,0071 PROFI 1701 PROFITRONIC 1361 1201,1181,0021 PROLINE 8041 7951,6931,2541,1981,1661 1361,1321,1291,1181,1871 PROSCAN 1801 PROSONIC 4381 1861,1851,1651,1361,1231 1181,0411,0041 PROTEC 0991 0951,0081,0021 PROTECH 2541 1861,1811,1701,1361,1351 1201,1181,0071 PROTON 1761,1111,0081 PROVISION 1361,1181,0041 PULSER 1801 1111,0911,0081,0021 PVISION 1831 PYE 1361,1351,1321,1221 1181,1021,0021 PYMI 1701,0081 QLIVE 7481,7351,3611 QMAX 2601 QUADRO 4371,2541,1181 QUASAR 1711,1701,0991 QUELLE 1861 1811,1511,1441,1361,1171 0371,0341,0171,0151	QUESTA 1061 QUIERO 1301 R LINE 1361,1181,0021 RADIALVA 1361 1211,1181,0911,0751,0071 RADIO SHACK 1361 RADIOLA 1861 1361,1321,1181,1141,0021 RADIOMARELLI 2191 1361,1181,1021,0991,0961 PANORAMIA 0311,0181 RADIOTONE 2541 1811,1701,1361,1181,0411 0081,0021 RADUGA 0071 RANK 0311 RANK ARENA 1061 RCA 3591,1801,1721,1291 1221 REALISTIC 1761 RECCO 3571 RECOR 1361,1181 RECTILIGNE 1361,1181 RED STAR 1361,1181 REDIFFUSION 1061 0321,0311,0151 REFLEX 1361,1181 REFLEXION 6411,2101,2091 REGENTE 0081 REOC 0041 REVOC 1361,1181,0411,0021 REX 1811,1511,1001,0991 0811,0391,0381 RFT 2191,1811,1361,1181 1021,0411,0401,0391,0381 RHAPSODY 1851,0951 RICE CLUB 1801 RICOH 1361,1181 RINEX 1821,1811 R-LINE 0071 RMB 1111 RM-U301 1281 ROADSTAR 4371 2541,1961,1811,1701,1361 1181,1081,0081,0041 ROBOTRON 1021 RODEX 1361,1181 ROKU TV 3381 ROSITA 0081 ROSNER 0951 ROWA 1861,1851,1821,1811 1701,0081,0031 ROYAL 1731,0081 ROYAL LUX 1221,0411 RUBIN 1501,0071,0021 RUKOPIR 1361,1181 RUNCO 1801 SABA 6931,2541,2191,2091 1871,1271,1251,1241,1181 1021,0961,0851,0841,0761 0321 SACCS 1341 SADCO 0071 SAGEM 2331,1791,1281 SAISHO 1861 1811,1701,1171,1091,0951 0461,0071,0021 SAIVOD 1661,1361,1181 SAKAI 0071 SAKIO 0081 SALORA 4111 2541,1871,1771,1181,0781 0571,0561,0551,0371,0321 SALSA 1221 SAMBERS 1201 0961,0951,0671,0371,0351 0331 SAMPO 1111 SAMSUNG 3831 2541,1791,1761,1111 SAMSUX 1111 SAMUS 7971,7961 SANDRA 1861,1851 SANELA 1341 SANG 7511,7501,7491,4111 1111 SANKY 6931 SANSUI 1801,1361,1111,0081 1701 SANTON 0751 SANY 4011,6811,2541,1871 1861,1751,1701,1441,1361 1171,1061,0651,0481,0411 0391,0381 SASO 0911 SAVE 1361,1181 SBR 1361,1321,1191,1181 1141,0021 SCEPTRE 2491 SCHAUB LORENZ 2831 2101,1871,1831,1731,1231	SCHEIDER 0321,0041 4451 3451,4111,3211,2541,1861 1511,1321,1181,1151,1081 0991,0971,0821,0391,0151 0081,0051,0041,1871 SCHONTECH 1871 SCOTLAND 0071 SCOTT 2261,1971,1761,1111 1061,0141 SEDEA 2991 SEEVUE 7521 SEG 2541,2321,1861,1811 1701,1201,1181,1111,1061 0991,0951,1351,0041 SEI 1361,1351,1301,1281 1201,1181,1021,0071 SEIKI 2621 SEI-SINUDYNE 2191 1361,1301,1281,1201,1151 1091,1021,0461,0291,0141 SEIZO 2621,2441 SELECLINE 7351,1871 SELECO 2541 1811,1511,1181,0861,0811 0791,0771,0381,0201 SEMUA 1111 SENCOR 2541,6591 SENCORA 1701,0081 SENTRA 1701 1391,1351,1081,0151 SERINO 1851,1721 SHARP 2091,3871,3861,3421 6811,6561,3241,2001,1871 1061 SHINTOM 0141 SHINTOSHI 1361,1181 SHIVAKI 2541 2251,1761,1361,1231,1181 0021 SHORAI 1151 SHOW 1821,1811,1701,0081 SHIAREM 2191 1201,1021,0961,0951,0671 1021,1081,0081,0071 SICATEL 0581,0411 SIEMENS 1361 1331,1181,1111,1051,0471 0461,0451,0441,0251,0151 SIERA 1361,1321,1181,1141 0411,0031,0021 SIGMAX 1801 SIGNATURE 0141 SILVA 1851,1361,1181,0151 0081 SILVA SCHNEIDER 2951 SILVER 1591 1361,1181,1081,1061,0151 0071 SILVERCREST 2541 1871,1181 SIMPLY 2601 SINGER 2191 1701,1361,1221,1201,1021 1001,0991,0671,0581,0281 SINODYNE 0021 SINOTEC 1821,1731 SINUUDYNE 1731 1301,1281,1201,1021,0151 1761,1361,1181 SKY 1761,1361,1181 SKYMASTER 7691,7681,7671 SKYTECH 7531,1871 SKYWORTH 3431,1401 SMARAGD 0111 SMART 7711,7701,2641 SMART TECH 4111 SNYDER 0021 SOGO 7351,2101 SOKOL 1511,0071 SOLAVOX 1361 1181,0321,0181,0151,0071 SONIKO 1361,1181 SONIQ 2161,2151,2141,2131 2121 SONITRON 1861 1771,0501,0411 SONNECLAIR 1361,1181 SONOKO 4111 1861,1811,1701,1361,1181 0951,0081,0021 SONOLOR 1771 1301,1281,0581,0321 SONTEC 1701 1361,1181,0411,0021 SONY 3391,6391,4151,3611 0141 SOUND & VISION 1361 1231,1201,1181,1081 SOUNDESIGN 2261 1801,1761,1111,1061,0141 SOUNDMASTER 0081	SOUNDWAVE 1591,1361,1181 SOYO 4381 SPECTRA 1701,1231 SPECTRICIAN 1111,0021 SSANGYONG 1701 STAKSONIC 1701 STANDARD 4381 1861,1701,1361,1231,1181 1081,0951,0081 STAR 0991 STARLIGHT 2521,7541 STARLITE 1811 1701,1361,1181,0081,0071 STARLUX 0081 STELLA 7571 7561,7551,3391,0771 STERN 1811,1511,0811,0391 0381,0291,0231,0151,0071 STRATO 1811 1701,1361,1181 STREAM SYSTEM 6851 STRONG 3441 3431,2741,2581,1661 STYLANDIA 1861 SUNGUO 4981 SUNIC LINE 1361,1181 SUNKAI 1361 1181,1151,1091,1081 SUNNY 4451,0001 SUNRISE 1581 SUNSTAR 1811 1701,1361,1181,0081 SUNSTECH 4111,1871 SUNWOOD 1701 1361,1181,0081,0021 SUPERIOR 7091 SUPERLA 1861,1851 SUPERSONIC 1821 1811,1771,1701 SUPRETECH 1851 1701,1361,1181,0151,0081 SUPERVISION 1821,1811 SUPRA 7811,7801,6931,2781 2601,2411,1761,1701,1391 1231,0081 SUPREMACY 1111,1061 SUPREME 0141 SURE 0991 1221,0751 SUSUMU 1721,0071 SUTRON 1701,0081 SVA 1821,1811 SVAN 1871 SVASA 1821,1811,1771 SWISSTEC 2091 SYC LINE 0081 SYDNEY 1861,1851,0951 SYLVANIA 1051 SYMPHONIC 1111,1061,0141 SYSLINE 1361,1181 SYTONG 1851 TANDBERG 1211 0911,0421,0291,0151,0071 TANDY 1861,1721,1081,0991 0951,0071 TASHIKO 1861 1851,1751,1191,1061,0951 0071 TATUNG 3181 3171,1861,1831,1361,1171 0951 TCL 3441,4131,8241,6731 4211,3571,3381,2721,1481 TCM 1651,0041 TD 1871 TD SYSTEMS 8161,7581 TEAC 1861,1821,1811,1761 1751,1701,1361,1351,1181 0041 TEAK 0081 TEC 1861,1701,1511,1361 1251,1231,1221,0991,0951 0691,0151 TECHLINE 2541 1871,1661,1361,1181 TECHNICAL 2541,1181 TECHNICS 1711,0131,0021 TECHNIKA 3401 2091,6811,2951,2541,1981 1871,1651 TECHNILAND 0021 TECHNISAT 1361 1181,0731,0651,0071 TECHNISSON 0041 TECHNOL 0081 TECHNOL ACE 1851 1821,1811 TECHNOSONIC 4371 TECHWOOD 2541 1871,1801,1661,1651,1181 0141 TECNIMAGEN 0041	TECNISON 2541,1181,0081 TEDELEX 4381 1861,1821,1771,1731,1701 1361,1181,0081,0031 TEIRON 1701 TEK 1821,1701 TEKNANT 0081,0021 TEKNIKA 1801,1111,0141 TEKON 1801,0081 TELE SYSTEM 7591 7091,1871 TELEAVIA 1271 1241,1211,1071,0931,0851 0841 TELECOR 1861 1361,1181,0071 TELEFAC 0081 TELEFUNKEN 1871 4191,6741,4201,4371,1821 1251,1221,0881,0141,0031 TELEFUSION 1361,1181 TELEGAZI 1811 1361,1181,0071 TELEKA 1871 TELEMEISTER 1361,1181 TELEOPTA 0081 TELEPRENT 0021 TELESONIC 1361,1181 TELESTAR 1701 1361,1181,0081 TELETECH 2541 2321,1701,1361,1181,0991 0081,1871 TELETON 1861 1511,1351,1061,0951,0811 0151,0071 TELEVIDEON 1851,0071 TELEVIEW 1361,1181 TELEVISIO 0581 TELEXA 1201 TELIVA 0911 TEMPEST 1811 1701,1361,1181,0081 TENNESSEE 1361,1181 TENSAT 2541,2081 1861,1701,1591,1441,1231 1181,1151,1081,0951,0661 0501,0071 TENSION 1701 TESLA 4431,4351,4341,4331 4321,4311,4301,4291,4281 4221,3431,2541,1291,2231 1651,1361,1281,1181,0041 0021 TEVION 2541 1361,1181,0041,0021 TEXET 1861,1851,1701,1231 0951 THOMAS 1801 1111,0911,0141,0081,0021 THOMSON 6731 3441,6551,4211,2721,1851 1471,1251,1241,0921,0771 THORN 1531,1441,1391,1361 1341,1301,1281,1231,1221 1141,1131,1061,0971,0941 0651,0611,0511,0501,0481 0451,0331,0151,0141,0011 THORN-FERGUSON 1341 1221,1131,0971,0941,0611 0151,0021 TMK 1801,1761 TOBO 0081 TOKAI 1861,1701,1361,1231 1181,0071,0021 TOKYO 1851,1801,1581 TONGTEL 0031 TOP SHOW 1821,1811,1701 TOPLINE 2541,1181 TOSHIBA 4181 2861,4061,6841,6811,6441 2541,1871,1181,1821,1791 0041 TOSONIC 1801,1111 TOTEVISION 1111 TOWADA 1861 1351,1201,0181 TOYODA 1811,1701 TRAKTON 1861,1811,1701 TRANS CONTINENTS 1861 1361,1181 TRANSONIC 1821 1811,1701,1361,1181,0031 TRANSTEC 1851 TRC 1081,0081 TREVI 4111,0081 TRIAD 1701,1361,1181,0021 TRIDENT 1861,0951 TRILUX 0021 TRISTRAP 1811,1081 TRIUMPH 1361,1181,0461 TRIVISION 0081	TUCSON 1651 TURBO-X 7351 TVTEXT 95 1361 1511,1361,1231,1181 0811,0411,0161,0151,0021 ULTRAVOX 2191 1851,1361,1231,1201,1021 1001,0991,0951,0221 UMA 0911,0751,0311,0181 0021 UNIC LINE 1361,1351,1181 UNIDEN 3591 3441,2541,1871,0131 UNIMOR 0021 UNITED 1871 1591,1361,1181,1161,0041 0031 UNIVERSAL 0041 UNIVERSUM 2901 2541,1861,1811,1791,1751 1701,1441,1301,1281,1271 1211,1181,1171,1061,0991 0811,0661,0521,0501,0451 0411,0151,1871 UNIVOX 1361 1341,1181,1021,0181,0071 URANYA 0081 UTAX 0071 V7 VIDEOSEVEN 1761 VANGUARD 0081,1871 V20 TECH 2101 VEDO 0081 VECTOR RESEARCH 7851 VENTURER 2161 VESTEL 4421 2541,1871,1181 VEXA 1701,1361,1181,0081 0021 VICTOR 1741 VIDEO SYSTEM 1361 1181,0021 VIDEOLÓGIC 1851 VIDEOLÓGIQUE 1861 1851,1081,0951 VIDEOSAT 0991 VIDEOTECHNIC 1861 1851,1231 VIDEOTON 2541 1181,0931,0901,0221 VIDIKRON 1201 VIDION 0081 VIDTECH 1761,1061 VIEWPIA 7091 VIEWSONIC 8211 VINCHI 4111 VISIOLA 1851 VISION 4171 2601,1861,1811,1361,1181 0081 VISIVO 7231 VISTAR 0151 VITYAZ 1521,0071 VIVAX 8191,4451,4391,4381 4371,4281,4221,4111,3571 2601,2121,1651 VIVID 1651 VIZIO 1761,3841 VODAFONE 6911 VORTEC 1361,1181,0021 VORTEX 7601,7451,4111 VOX 1871 VOXSON 2191 1761,1361,1181,1021,0181 0151,0071,0021 VU 3951,2101 WALKER 2541,1871 WALKIE 1511 WALTHAM 1861 1361,1261,0951,0931,0751 0321,0221,1871 WANSÁ 2601 WATSON 2541 1701,1361,1181,1081,0081 0071,0021,1871 WATT RADIO 1851 1351,1201,0951,0671,0591 0221,0181,0151,0071 WEGA 2191,1361,1181,1061 1021 WEGAVOX 1701 1361,1181,0991,0591,0081 0021 WELLINGTON 7481 WELLTECH 0041 WELTBlick 1861 1361,1181,0021 WESTINGHOUSE 3381 WESTINGHOUSE (ROKU TV) 3381 WESTON 1361,1181 WHARFEDALE 1821	1361,1181,1021,0021 WHITE-WESTINGHOUSE 1851 1361,0951 WILSON 2541,1181 WINDSOR 2541,1181,1871 WINSTON 0081,0021 WINEEL 0041 WINTERNITZ 0081 WORLD-TECH 1231 WORLDVIEW 0081,0021 XIAOMI 6941 XLOGIC 1821 XORO 8091,6521,4491,4481 4471,4401,2501,2421,2061 1731 XRYPTON 1361,1181 X-VIEW 1831 YAMAMA 1711 YAMISHI 1861,1361,1181 YOKAN 1361,1181 YOKO 1851,1811,1231,1081 1001,0991,0951,0911,0411 0181,0081,0021 YORK 0501,0021 YORX 1081 ZANUSSI 1861 0811,0181,0151 ZENITH 0141,0021 ZEPHIR 7901,7611,2441 ZUTEST 6821	SAT / CABLE Code List ABCOM 0544 ADB 2474 AIRTEL 4024 AKAI 0194 ALBA 3514,3464,3154,1964 1774,0194 ALBIS 2984 ALCAD 0884 ALITICE 1294 AMIKO 4354,4344 AMLOGIC								