


FLIPPER[®]
Two Device Universal



Code List
Europe

TV Code List

ACCENT	0301,2551,2791
	3601
ACCUPHASE	2791
ACEC	2741
ACTION	0051,0301,2391
ADCOM	2711
ADMIRAL	0051,0301,0721
	0981,1131,1571,2571
	3661,3831,3881
ADYSON	0051,2391,3911
	3921
AEA	2551,2791
AEG	3531,3681
AGASHI	3831,3911,3921
AGEF	2571
AIKO	0301,2551,2751,2791
	3601,3831,3891,3911,3921
AIM	2551,2791,3681
	3721,3841
AKAI	0051,0301,0671,0741
	0851,0871,0991,1001,1491
	2371,2391,2551,2751,2791
	3331,3541,3601,3681,3711
	3721,3831,3881,3891,3901
	3911,3921
AKASHI	3601
AKIBA	2551,2791
AKITO	2551,2791
AKURA	0051,0301,2551,2791
	3541,3601,3831
ALARON	3911
ALBA	0051,0301,1181,1571
	1681,2541,2551,2791
	3541,3601,3881,3911
ALFA	0051
ALLORGAN	1901,3921
ALLSTAR	0051,2551,2791
AMPLIVISION	1181,3921
AMSTRAD	0301,0981,2551
	2791,3601,3831
ANAM	2551,2791,3601,3611
ANAM NATIONAL	2551,2791
	3611
	3531
ANDERSSON	
ANGLO	0301,3601,3831
ANITECH	0051,0301,1111
	2391,2551,2581
	2791,3601,3831
ANSONIC	0301,1181,2551
	2581,2631,2741
	2791,3601,3881
AOC	0051,2391,2391,4261
AR SYSTEM	1741,2551,2791
ARCEN CIEL	1991,2341,2591
	2641,2681
ARCAM	2641,3911,3921,4271
ARDEM	2551,2791,3541
ARISTONA	0051,2471,2551
	2741,2791
ART TECH	0051
ARTHUR-MARTIN	0771,3881
ASA	1101,1371,1381
	1471,2571,3881
ASBERG	0051,1111,1571
	2551,2581,2791
	0301,3601
ASORA	
ASTON	4281
ASTRA	0301,2551,2791
ASUKA	3831,3911,3921

TV Code List

ATD		3841
ATLANTIC	0051,1901,2551	
		2791,3911
ATORI		0301,3601
AURO		0301
AUCHAN		0771,3881
AUDIOSONIC	0051,0301,1181	
	2551,2591,2631,2791,3331	
	3541,3601,3831,3921	
AUDIOTON		0301,1181
		3831,3921
AUDIOVOX		0051
AUDIOWORLD		3841
AUMARK		3811
AUTOVOX	1901,2481,2571	
		2771,3921
AWA	0301,2411,2531,2541	
	2551,2631,2791,3601,3681	
	3831,3911,3921,4141,4231	
AXXENT		3601
AXXON		3541
BAIRD	2591,2621,2801	
	3681,3721,3921	
BANG & OLUFSEN		2571
BARCO		3881
BASICLINE	0051,0301,2551	
	2631,2791,3601,3881,3921	
BASTIDE		3921
BAUER		3601,3831,3841
BAUR	0051,0181,0301,0411	
	0421,0431,0441,0471,0791	
	1281,1291,1301,2551,2691	
	2721,2751,2771,2781,2791	
		3601,3891
BAZIN		3921
BBK	3151,3171,3181	
BEAUMARK		3711
BEC		0051
BECRESE		0051,2391
BEKO	0051,1181,1621,2021	
	2551,2791,3331,3541,3681	
BELL & HOWELL		0051
BELSON		3851
BENCHMARK-BEAUMARK		0051,0301,2391
		3921
BEON	0051,1571,2551,2791	
BEST		1181
BESTAR	0051,0801,1181	
	2551,2631,2791	
BESTAR-DAEWOO		2631
BEXA		4421
BIGSTON		0301
BINATONE		3921
BLACK DIAMOND		2791,3531
BLACK PANTHER		2581
BLAUPUNKT	1231,1241,1251	
	1271,1281,1301,1321,1341	
	2371,2441,2451,2751,3701	
BLAUPUNLET		2781
BLUE SKY	0051,2551,2791	
	3331,3541,3851	
BONDSTEC		2481,3601,3921
BOSCH		2441
BPL		2551,2791
BRANDT	1991,2591,2601	
	2611,2621,2641,2661,2681	
		2711
BRANDT ELECTRONIQUE	1851	
	1991,2341,2601,2611,2681	

TV Code List

BRENDSTAR		0301
BRINKMANN	0051,1571	
		2551,2791
BRIORVEGA	0051,0981,2551	
		2571,2791
BRIORRYEGA		0051
BRITANNIA		3911,3921
BROCKWOOD		2391
BROKSONIC		2391
BROTHER		3831
BRUNS		2571
BSR	0621,0751,3881,3891	
BUSH	0051,0621,0871,1681	
	2541,2551,2631,2771,2791	
	3541,3601,3721,3831,3841	
		3881,3891,3921
CAMERON		3021
CAMPLE		2391
CANDLE		2391
CAPEHART		0051,2391
CAPSONIC		3831
CARAD		2551,2791
CARENA		2551,2791
CARREFOUR	0051,2541,2551	
		2791
CARVER		0051,3701
CASCADE		2551,2791,3601
CASIO	2551,2771,2791,3881	
CATHAY		0051,2551,2791
CCE		2551,2791,3921
CENTURION		0051,2551,2791
CENTURY		2201,2571,2761
CGE	0301,0691,0871,1111	
	1181,1571,2201,2461,2641	
CGM		0301
CIE		0301
CIMLINE		0301,3601
CIRCUIT CITY		2391
CITIZEN		0051,2391,3811
CITY		0301,3601
CLARIVOX	2171,2551,2581,2791	
CLATRONIC	0301,1111,1181	
	2191,2201,2551,2581,2791	
	3531,3541,3601,3681,3831	
		3921
CMS		3911
CMS HIGHTEC		3921
COLORTYME		0051
COMPUTRON		0301
CONCORDE		0301,3601
CONDOR	0051,0301,1181	
	1571,2551,2581,2791,3601	
		3831,3881,3911
CONIC		0051,2391
CONRAD		2551,2791
CONTEC		0301
	2531,2541,2551,2791,3601	
		3831,3911
CONTINENTAL EDISON		0331
	1991,2341,2601,2641,2681	
CORONADO		2391
COSMEL	0301,2551,2791,3601	
CRAIG		0051
CROSLEY	0051,0701,1111	
	2201,2571,3881	
CROWN		0051,0301,1111
	1181,2391,2551,2791,3331	
	3541,3601,3681,3691,3721	

TV Code List

CRYSTAL		0051
CS ELECTRONICS		3911
CTC CLATRONIC		1571
CURTIS MATHES	0051,2391	
		3661,3811
DAEWOO	0051,0271,0281	
	0291,0301,1751,2391,2551	
	2631,2791,3541,3601,3841	
		3911,3921,4291
DAICHI		0301
DAINICHI		3911
DANSAI	2391,2541,2551,2791	
	3601,3721,3831,3911,3921	
DANTAX	1181,3331,3541,3681	
DATSURA		3721
DAWA	0051,2551,2791,3601	
DAYTEK		3831,3841
DAYTRON	0301,2391,2551	
	2631,2791,3601	
DE GRAAF		3721,3881,3901
DECCA		0051,2141
		2551,2791,3921
DEITRON		2551,2631,2791
DENKO		3831
DENVER		0301,2551
		2791,3681,3861
DER		2801
DESMET	0051,0301,2551	
		2571,2791,3601
DIAMANT		2551,2791
DIAMOND		0301,3601
		3831,3841,3911
DIGILINE		2551,2791
DIGILOGIC		3951
DIGITOR		2551,2791,3891
DIK		2551,2791
DIXI	0051,0301,2551	
		2571,2791,3601,3921
DL		3861
DORIC		2771
DSC		4231,4241
DSE	2871,2891,2901	
		2911,2921
		0301,3601
DTS		
DUAL	0051,0051,0301,0981	
	1161,2491,2551,2621,2641	
		2771,2791,3881,3921
DUINAMAI		4301
DUMONT	1571,2391,2571	
		2581,3921
DUNAI		3881
DUX	2551,2741,2791	
DVICO		4411
D-VISION		2551,2791
DYNAMIC		0301
DYNATECH		2391
DYNATRON	2551,2741,2791	
E-MAX		3681
ECCO		3841
EDISON		2591
ELBE	0711,0981,1151,1181	
	2171,2551,2751,2761	
	2791,3881,3891,3921	
ELBIT		0051
ELCIT	2571,2581,3881	
ELECS		0051
ELECTRATUNE		2391
ELECTRO TECH		0301
ELECTROHOME		2391

TV Code List

MERRITT	3901
METZ	1191,1241,1281,1301, 1331,2231,2551,2571,2751, 2781,2791,3531,3861
MGA	2551,2791,3711
MICROMAXX	2551,2791
MICROTEK	3831,3841
MIDLAND	2391
MIKOMI	3531
MINATO	2551,2791
MINERVA	1241,1301,2411, 2751,2781
MINOKA	0051,2551,2791,4341
MISTRAL ELECTRONIC	2801
MITSUBISHI	0051,0301,2301, 2311,2411,2421,2511,2541, 2551,2571,2791,2801,3661, 3711,3721
MITSURI GENERAL	3881
MIVAR	1131,1151,1161,1181, 2161,3911,3921
MONACO	3601
MORGAN'S	2551,2791
MOTOROLA	0051,3661
MTC	1181,2391,2771,3811, 3881,3891,3911
MTLOGIC	3541
MULTIBROADCAST	2801
MULTISTANDARD	2581
MULTITEC	2551,2791
MULTITECH	0051,0301,1111, 1181,2391,2551,2581,2771, 2791,3601,3831,3911,3921
MURPHY	3881,3911
MUSIKLAND	2551,2791
MYCOM	3711
MYRVAD	2551,2791
NAD	3711,3881,3891
NAIKO	2551,2791,3681,4351
NAKIMURA	2551,2631,2791
NAMSUNC	0301
NAONIS	0721,3881
NATIONAL	0051,0351
NEC	0301,2531,2541,2551, 2631,2791,3601,3691, 3701,3861,3921
NECKERMANN	0051,0301, 0431,0441,0501,0791,0921, 0981,1181,1241,1261,1281, 1301,1331,2151,2441,2451, 2551,2571,2691,2721,2751, 2771,2781,2791,3881,3921
NEI	0051,2551,2791,3881
NETSAT	2551,2791
NEUFUNK	2551,2791, 3541,3601
NEWTECH	3601,3921
NEWTECH	0051,0301,2551, 2621,2791
NICAMAGIC	3911
NIKKAI	0051,2391,2541,2551, 2791,3601,3831,3911,3921
NIKKIE	3541
NIKKO	1711,3711
NOBLEX	0261,0301
NOBLIKO	1081,1111, 2581,3911
NOGAMATIC	1991,2341,2591, 2641,2681

TV Code List

NOKIA	0241,0301,0631,0661, 0671,0721,0731,0741,0811, 0831,0861,0901,0931,0991, 0991,1001,1041,1051,1391, 1401,1421,1431,1481,1501, 1511,1521,1541,1571,1821, 2591,2631,2771,3681,3681, 3721,3881,3891,3901
NOKIA AKAI	0851
NONAME	0051
NORDIC	3921
NORDMENDE	1791,1851, 1921,1961,1991,2021,2341, 2551,2591,2601,2611,2621, 2641,2661,2681,2701,2791, 3541,3881
NORFOLK	3881
NORMEREL	2551,2791
NOVABEAM	0051
NOVAK	2741
NOVATRONIC	0051,0301, 2551,2631,2791
NURNBERG	3881,3891
NU-TEC	3841
O GENERAL	0301
OCEANIC	0771,0811,0991, 1051,1501,1521,2011, 3721,3881,3891,3901
ODEON	0301,1181,2551,2791, 3601,3831,4431,4441
OLYMPIC	0301
OMEGA	3831,3841
ONCEAS	0301
ONWA	2581
OPERA	0051,2551,2791
OPTIMUS	3611
OPTONICA	3661
ORBIT	0051,2551,2791
ORIENT	0301
ORION	0051,0301,0961,0971, 2111,2391,2531,2551,2581, 2791,3541,3601,3831
ORLINE	2551,2791
ORMOND	2551,2791
OSAKI	2551,2631,2791,3831, 3921
OSIO	2551,2791
OSUME	2541,2551,2791
OTF	0301
OTTO VERSAND	0051,0301, 0411,0421,0431,0441,0451, 0621,0791,0801,1261,1271, 1281,1331,2021,2371,2481, 2491,2541,2551,2591,2621, 2691,2721,2751,2771,2781, 2791,3601,3661,3891,3921
OTTO-VERSAND	0441,0471,0561, 0801,1241,1301,1631,2111
PACIFIC	2551,2791,3541
PAEL	1081,3911
PALLADIUM	0051,1181,1281, 2551,2571,2691,2721,2751, 2771,2781,2791,3541,3881, 3921
PALSONIC	2551,2791,3591,3831, 3841,3921,4451,4461,4471
PANAMA	0301,2551,2791, 3601,3831,3911,3921

TV Code List

PANASHIBA	0301,3591
PANASONIC	0051,0351,0361, 0371,0381,0391,1191,2361, 2371,2411,2551,2791,3221, 3591,3611,3621,3631,3641, 3651,3711,3811,3881,3891, 3901,4041,4051,4061
PANASONIC	4361
PANAVISION	2551,2791
PANAVOX	0301
PANORAMA	0301
PATHE CINEMA	1161,1181, 2761,2771,3881,3911
PATHE MARCONI	1991,2341, 2591,2641,2681
PAUSA	0301,3601
PECE/PEG	2391
PDP	4481
PENNEY	2391,2391
PERDIO	2551,2791,3881,3911
PERFEKT	0051,2551,2791
PHILCO	0051,0301,0691,0701, 1111,1181,1571,2201,2551, 2571,2791,3881
PHILEX	2801,3881
PHILHARMONIC	3921
PHILIPS	2551,2561,2571, 2621,2631,2651,2741,2751, 2761,2781,2791,2801,2811, 3601,3891,3931,4371
PHILIPS (F)	0051,2471
PHOCUS	3541
PHOENIX	0051,1181,2551, 2571,2791,3881,3911
PHONOLA	0051,2471,2551, 2571,2741,2791,2801,3911
PILOT	2551,2791
PIONEER	0051,0761,1181, 1791,2551,2591,2601,2621, 2651,2791,3201,3701,3871, 3881,3891,4071,4081
PLANTRON	0051,0301,2551, 2791,3601,3831
PLAYSONIC	3331,3541,3921
POLICOM	2571,2581,2591, 2681,2761,3881,3891
POPPY	0301,3601
PORTLAND	2391,2631
POWERPOINT	3841
PRANDONI PRINCE	0721,1081
PRANDONI-PRINCE	2151,3891
PRECISION	3921
PREMIER	3601,3831
PRIMA	0051,0301,2391, 3601,3831
PRINCESS	0301,3841
PRINZ	2771,3891
PROELCO	0051
PROFEX	0301,0801,1111, 3601,3881,3891
PROFI	3601
PROFITRONIC	0051,2551, 2581,2791
PROLINE	2551,2711,2741,2791
PROSONIC	1181,2551,2631, 2791,3541,3911,3921
PROTEC	0051,0301
PROTECH	2551,2581,2771, 3601,3831,3881,3921

TV Code List

PROTECT	2791
PROTON	0301,2391,3711
PROVISION	2551,2791,3541
PULSER	0051,0301,2391
PVISION	
PYE	0051,2551,2571,2631, 2741,2771,2781,2791
PYMI	0301,3601
QUASAR	3601,3611
QUELLE	0051,0301,0411,0421, 0431,0441,0451,0471,0501, 0621,0871,0981,0991,1081, 1101,1131,1241,1271,1281, 1301,1331,1371,1381,1471, 1521,1661,1671,1901,2311, 2371,2391,2441,2451,2461, 2481,2531,2541,2551,2591, 2681,2691,2721,2751,2771, 2781,2791,3601,3831,3891
QUESTA	3921
R LINE	0051,2551,2791
RADIALVA	2551,2591,2601, 2791,3881
RADIO SHACK	2391,2551,2791
RADIOLA	0051,2471,2551, 2741,2791,3921
RADIOMARELLI	2151,2551, 2571,2791
RADIO SHACK	3711
RADIOTONE	2791
RADIOTONE	0051,0301,1181, 2551,3601,3831
RADUGA	3141
RANK ARENA	2541
RANK/RUSH/MURPHY	1141
RCA	2611,2621,2701,2711, 3661,3661,3941
REALISTIC	3711
RECOR	2551,2791
RECORD	0051,3141
RECTILIGNE	2551,2791
REDIFFUSION	2541,3891,3901
REDSTAR	2551,2791
REFLEX	2551,2791
REGENTE	0301
REOC	3541
REVOX	0051,1181,2551,2791
REVOX/STUDER	0051
REX	0711,0751,0901,1161, 1901,2201,3831,3881
RFT	1161,1181,2551, 2571,2791,3831
RHAPSODY	3911
RICOH	2551,2791
RINEX	3831,3841
R-LINE	3881
RMB	2391
ROADSTAR	0301,2551,2791, 3541,3601,3831,4171
ROBOTRON	2571
RODEX	2551,2791
ROSITA	0301
ROSA	0301,3601,3831,3841, 3861,3911,3921
ROYAL	0301,3681
ROYAL LUX	1181,2611
RUBIN	3141
RUKOPIR	2551,2791

TV Code List

SABA	0661,0861,1791,1851, 1991,2021,2041,2151,2341, 2571,2591,2601,2611,2621, 2641,2661,2681,2701,2711, 3541,3711,3881,3891,3901
SACCS	2761
SADKO	3141
SAGEM	3741,3741
SAISHO	0051,2531,3601, 3831,3881,3921
SAIVOD	2551,2791,3531
SAKAI	3881
SAKURA	0301
SALORA	0631,0741,0791, 0811,0921,0991,1001,1041, 1051,1131,1391,1471,1491, 1501,1521,1541,1821,2771, 3721,3881,3891,3901
SALSA	2611
SAMBERS	1081,1111,1131, 2151,2581
SAMPO	2391
SAMSUNG	0051,0051,0161, 0181,0261,0301,0301,1131, 1181,1661,2391,2401,2551, 2791,3211,3601,3661,3711, 3721,3741,3751,3761,3771, 3781,3791,3811,3821,3831, 3861,3881,3881,3911,3921, 4091,4101,4111,4121
SAMSUX	2391
SANDRA	3911,3921
SANELA	2761
SANKY	2391
SANSUI	0051,0301,2391, 2551,2791
SANTON	3601
SANYO	0301,1161,1181,1181, 1671,2311,2411,2531,3211, 2541,2551,2791,2791,3601, 3701,3721,3721,3881,3911, 3921
SAVE	2551,2791
SBR	0051,2471,2551,2561, 2741,2791,2801
SCHAUB LORENZ	0991,1051, 2631,2771,3541,3681, 3871,3891,3901
SCHNEIDER	0051,0161,0171, 0301,0861,0941,0981,1161, 2471,2481,2491,2551,2621, 2741,2771,2791,3541,3881, 3891,3921
SCHNEIDER (F)	2471
SCOTLAND	3881
SCOTT	2391,3711,4181
SEARS	3711
SEG	0301,0471,1111,2391, 2541,2551,2581,2771,2791, 3531,3541,3601,3831,3881, 3911,3921
SEI	2551,2571,2581,2691, 2721,2771,2791,3881
SEI-SINUDYNE	0051,0701, 2551,2571,2581, 2691,2721,2791
SELECO	0711,0721,0751,0981, 1011,1161,1901,2001, 2311,2541,3831,3881

TV Code List

SEMUA	2391
SENCORA	0301,3601
SENTRA	0861,2771,3601
SERINO	3661,3911
SHARP	0561,0571,0581,0601, 2311,2391,2541,2801,2801, 2841,3231,3531,3531,3661, 3671,3691,3691,3871,4191
SHINTOSHI	2551,2791
SHIVAKI	0051,2551,2631, 2791,3711
SHOW	0301,3601,3831,3841
SIAREM	0701,2161,2571, 2581,3881
SICATEL	1181
SIEMENS	0051,1241,1251, 1261,1271,1281,1291,1301, 1331,2391,2441,2451,2551, 2751,2781,2791,3891
SIERA	2551,2741,2791,3861
SIERRA	0051,1181,2471
SILMA	0051
SILVA	0301,2551,2791, 3891,3891,3911
SILVER	2541,2551,2791, 3331,3881,3891
SINGER	0051,0301,0941, 0941,2011,2191,2201,2201, 2551,2571,2581,2581,2611, 2791,3601,3881
SINOTEC	3681,3841
SINUDYNE	0051,0471,0721, 0941,0981,2111,2551,2571, 2581,2691,2721,2771,2791, 3681,3881,3891
SKY	2551,2791,3711
SMARAGD	0331
SNYDER	0051
SOKOL	3141
SOLAVOX	0861,2551,2791, 3881,3891,3901
SONIKO	2551,2791
SONIO	4491,4501,4511, 4521,4531,4541,4551,4561, 4571,4581,4591,4601,4611
SONITRON	1181,3721,3921
SONNECLAIR	2551,2791
SONOKO	0051,0301,2551, 2791,3601,3831,3921
SONOLOR	1181,3721,3921, 0991,2011,2691,2721,3721, 3881,3891,3901
SONTEC	0051,1181,2551,2791,3601
SONY	2531,2541, 2551,2581,2691,2721,2731, 2791,3661,3701,3801
SOUND & VISION	2551,2581, 2631,2791
SOUNDDESIGN	2391,3711
SOUNDMASTER	0301
SOUNDWAVE	2551,2791,3331
SPECTRA	3601
SPECTRICIAN	0051,2391
SSANGYONG	2551,2791
STAKSONIC	3601
STANDARD	0301,2551,2631, 2791,3601,3921
STARLITE	0301,2551,2791, 3601,3831,3881

TV Code List

STARLUX	0301
STERN	0711,0751,0981,1161, 1901,3831,3881
STRATO	2551,2791, 3601,3831
STRONG	3531
STYLANDIA	3921
SUNIC LINE	2551,2791
SUNKAI	2551,2791
SUNSTAR	0301,2551,2791, 3601,3831
SUNSTECH	4221
SUNVIEW	0051,0301,2551, 2791,3601
SUPERLA	3911,3921
SUPERSONIC	3601,3721, 3831,3841
SUPERTEC	0301
SUPERTECH	0301,0871,2551, 2791,3601,3911
SUPERVISION	3831,3841
SUPRA	0301,0301,2631, 3601,3711,3711
SUPREMACY	2391
SUSUMU	2601,2611
SUTRON	0301,3601
SVA	3831,3841
SVASA	3721,3831,3841
SYCLINE	0301
SYDNEY	3911,3921
SYLVANIA	0051,0051
SYMPHONIC	2391
SYSLINE	2551,2791
SYTONG	3911
TANDBERG	0981,1191,2591, 3881,3891
TANDY	3661,3881,3921 2321,2541,2561,
TASHIKO	3701,3881,3911,3921
TATUNG	0051,0191,2531, 2551,2791,3851,3921
TCM	3541
TEAC	2551,2771,2791,3541, 3601,3701,3711,3831, 3921
TEAK	0301
TEC	0751,0871,0981,2551, 2611,2661,2791,3601, 3881,3891,3921
TECH LINE	2551,2791,3531
TECHNICS	0051,0351,3611
TECHNIKA	4201
TECHNILAND	0051
TECHNISAT	2551,2791,3881
TECHNISSON	3541
TECHNOL	0301
TECHNOL ACE	3831,3841,3911
TECHWOOD	3531,3531
TECNISON	0301
TEDELEX	0301,2551,2791,3601, 3681,3721,3841,3861,3921
TEIRON	3601
TEK	3601,3841
TEKNANT	0051,0301
TEKNIKA	2391,3811
TEKON	0301
TELEAVIA	1991,2121,2341, 2591,2601,2621, 2641,2671,2681

TV Code List

TELECOR	2551,2791,3881,3921
TELEFAC	0301
TELEFUNKEN	1701,1851, 1951,1961,1971,2021,2041, 2461,2551,2591,2601,2611, 2621,2641,2661,2681,2711, 2791,3541,3841,3861
TELEFUSION	2551,2791
TELEGAZI	2551,2791,3831, 3881
TELEMEISTER	2551,2791
TELEOPTA	0301
TELESONIC	2551,2791
TELESTAR	0301,2551,2791, 3601
TELETECH	0301,2551,2791, 3601
TELETON	0751,1901,2541, 2771,3881,3921
TELEVIDEON	3881,3911
TELEVIEW	2551,2791
TELEVISQ	2011
TELEXA	2581
TEMPEST	0301,2551,2791, 3601,3831
TENNESSEE	2551,2791
TENSAI	0051,0301,0621,3601, 1631,2551,2631,2791,3331, 3881,3921
TENSON	0301,3601
TESLA	0051
TESLA ORAVA	0051
TEVISION	0051,2551,2791,3541
TEXTET	2631,3601,3911,3921
THOMAS	0051,0301,2391
THOMSON	2551,2591,2601, 2611,2621,2641,2661,2671, 2681,2681,2701,2711,2771, 2791,3041,3911,3941
THORN	0041,0051,0741,0861, 0921,1081,1591,1971,2131, 2171,2311,2411,2471,2551, 2591,2611,2621,2631,2691, 2721,2761,2791,2801,3891
THORN-FERGUSON	0051,0981, 1591,2021,2131,2171,2411, 2591,2611,2761,2801,3891
TMK	3711
TORO	0301
TOKAI	0051,2551,2631,2791, 3601,3881,3921
TOKYO	3911
TONGTEL	3861
TOP SHOW	3601,3831,3841
TOSHIBA	0001,0001,0011, 0021,0031,0041,1141,2541, 2591,2671,2751,3241,3531, 3541,3601,3611,3741,3811, 2581,3841,3921,4251,4381
TOSONIC	2391
TOWADA	2581,2771,3921
TOYODA	3601,3831
TRAKTON	3601,3831,3921
TRANS CONTINENS	2551,2791
TRANS-CONTINENTS	3921 2551,
TRANSONIC	2791,3601,3831, 3841,3861
TRANSTEC	3911

TV Code List

TREVI	0301
TRIAD	0051,2551,2791,3601
TRIDENT	3921
TRILUX	0051
TRISTRAR	2801,3831
TRIUMPH	2551,2791
TRIVISION	0301
TVTEXT 95	2791
UHER	0051,1181,1901,2551, 2631,2791
ULTRAFOX	2201
ULTRAVOX	0701,2191,2201, 2551,2571,2581,2631,2791, 3881,3911
UMA	0051
UNICLINE	2551,2771,2791
UNIMOR	0051
UNITED	2551,2791,3331, 3541,3861
UNIVERSAL	3541
UNIVERSUM	0051,0301,1181, 1281,1411,1471,1541,1681, 1901,2441,2531,2541,2551, 2591,2681,2691,2721,2771, 2781,2791,3531,3601,3701, 3741,3831,3881,3891,3921 2551,2571,2761,
UNIVOX	2791,3881
URANYA	0301
UTAX	3881
V7 VIDEOSEVEN	3711
VANGUARD	0301
VECO	0301
VESTEL	0051,1681,2551,2791, 3531,3881,3921,4391
VEXA	0051,0301,2551, 2791,3601
VICTOR	3691
VIDEO SYSTEM	0051,2551,2791
VIDEOLOGIC	3911
VIDEOLOGIQUE	3911,3921
VIDEOTECHNIC	2631,3911, 3921
VIDEOTON	0631,0651,0961, 1571,1791,2121,3881
VIDIKRON	2581
VIDION	0301
VIDITECH	2541,3711
VISIOLA	3911
VISION	0301,2551,2791, 3831,3921
VISION	0051
VISTAR	3891
VITYAZ	3141
VIZIO	4131
VORTEC	0051,2551,2791
VOXSON	0051,0771,2551, 2571,2791,3771,3881
WALTHAM	0631,0961,2121, 2551,2591,2601,2671,2791, 3881,3921
WARDS	0051
WATSON	0051,0301,2551, 2791,3601,3881
WATT RADIO	0701,1571, 2581,2771,3881,3911
WEGA	2221,2541,2551,2571,2791
WEGAVOX	0051,0301,1571, 2551,2791,3601

TV Code List

WELLTECH	3541
WELTBlick	0051,2551,2791, 3921
WESTON	2551,2791
WESTON	2791
WHAREFADALE	0051,0051, 2551,2551,2791,2791,3841, 3841,4211
WHITE WESTINGHOUSE	0051, 1571,2551,2791,3911
WINSTON	0051,0301
WINTEL	3541
WINTERNITZ	0301
WORLDVIEW	0051,0301
XLOGIC	3841
XRYPTON	2551,2791
X-VIEW	3851
YAMAHA	3611
YAMISHI	2551,2791,3921
YOKAN	2551,2791
YOKO	0051,0301,1181,2201, 2551,2791,3601,3831,3911, 3921
YORK	0051
ZANUSSI	0721,1901,3921
ZENITH	0051

Note: This is the end of TV code list, next section will be SAT and CTV code list.

SAT CTV Code List

AKAI	0263
ALBA	0263
ALBA	2003,2103
AMSTRAD	0283,0583,1573
AUSTAR	0463,0723,3013,3323
BT	0293,0633
BT VISION	3413
CABLETIME	2903,2913,2933
CAMBRIDGE	0023,0263
Canal + 'MEDIASAT'	2743
Canal + 'SYSTER+'	2733
Canal + 'TNT+'	2723
Canal sat PILOTIME	2753
CANAL+ 0353,1633,1643,2623	
CANAL+ CANALSAT	3333
Canal+ 'MEDIASAT MAX'	2763
CGV FREEVIEW	1653,1663, 1683,1843,2293
CLYDE CABLEVISION	2883
COMAG	3203
CYBERMAXX	2133,2243
CYTRON	2133,2243
DARK BOX	3153
DARTY	2543
D-BOX	3393
DGTECH	1753,1783
DIGITAL-SVR	3163
DILOG	3133
DR.HD	3353
DREAM	3403
DSE	1823
DUNE	3213
ECHOSTAR	0093
ECHOSTAR	2173

SAT CTV Code List

EURODEC	0213,0223,0233
EUROVOX	3363
FERGUSON	0013,3173,3313
FILMNET	2853,2893
FORCE	1093,1123
FOXTEL	0483,0743,0813, 1533,2263,2973,2983,2993
FREEBOX	2553
FREEBOX TV	2493,2503
FREEVIEW	1993,2003,2013, 2033,2043,2053,2063,2083, 2103,2113,2123,2143,2193, 2203,2223,2253
G.I.	3033
GEC	2883
GOLDSAT	3223
GOODMANS	2003,2063
GRUNDIG	0693,1573
GRUNDIG	2043
HIRSCHMANN	0433
HITACHI	2063
HK CABLE	3023,3073
HOMECAST	1803
HUMAX	1053,1893,1913, 1923,1933
HUMAX	2143
ICECRYPT	3233
ICECRYPT	3183
JERROLD	2873
IVC	0263
IVC	2063
KYOSTAR	0073
LENSON	2313,2323,2033, 2383,2403,2463
MATSUMI	2003,2063,2253
MEDION	0313,0333,2133,2243
METRONIC	0963,0973,1013, 1023,1033,2603,2653,2673, 2663
MICROMAXX	0313,0333
MICROMAXX	2133,2243
MICROSTAR	2133,2243
MOVIE TIME	2923
MYSTAR	3323
NIKKO	0123,0133
NOOS	2573
NOW BROADBAND TV	3063
NSC	2923
OCTAGON	3243
ONDIGITAL	0513,0853,0863, 1373,1383,1523,1553,1563
ONO	3343
OPTICUM	3253
OPTUVISION	3003
ORANGE	3263
PACE	0513,0563,0613,0623, 0793,0803,0873,1373,1573, 0783,1593
PACE	2013
PANASONIC	1573
PANASONIC	1973
PHILIPS	0803,0853,0863,1553, 1563,1943,2683,2693,2703, 2843
PHILIPS	2223,3083
PIONEER	2193
PREMIERE	2203,2223
SAGEM	0243,0923,1113,1393, 1603,2653,2723,3263

SAT CTV Code List

SAGEM	2123,3093,3103
SAMSUNG	1103,2953,3113,3123
SCHWAIGER	2093
SCIENTIFIC ATLANTA	2943,2963
SHARP	1963
SKY	3193
SKY (NZ)	1363,1423,1503, 1513,1953
SKY (SKY Digital)	0443,1573, 1583,1593
SKY HD	2633
SKY ITALY	1673
SKY MASTER	1343,1353,1433, 1443,1473,1483
SKY SATELLITE	1363,1423, 1503,1513
SKY+ (SKY Digital+)	1543
SKYMASTER	3043,3053
SMART	3273
Sonic Blue	3283
Sony	1573
SONY	1993
STARCOM	2873
STRONG	0073,1333,2713, 2793,2803,2813
STS	2923
TECHNIKA	3293
TECHNISAT	3303
TELE	2893
TELE+1	2893
TELEVISION	0003,0053,0303, 0473,0493,0503,0543,0653, 0703,0713,0823,1063,1073, 1403,1413,1453,1463,1493, 1693,1743
TEVION	2133,2243
THOMSON	1143,1603,2713, 2723
THOMSON	2083
THORN-FERGUSON	0013
TOKIWA	3373
TOPFIELD	1863,1873,1883
TOPWAY	2643
TOSHIBA	1383
TPS 'HD SAT'	2783
TPS 'Platinum'	2773
TRIAN	2303,2313,2323,2333, 2343,2353,2363,2393,2403, 2413,2423,2433,2443,2453, 2463
TUDI	2833
UNITED CABLE	2873
UPC	3383
VIRGIN MEDIA	3143
ZEHNDER	0203,0323
ZENITH	1583,2863
ZINWEL	1083