

COMMON CODES - TV	COMMON CODES - STB	COMMON CODES - STB	TV CODE LIST	TV CODE LIST	TV CODE LIST	SAT / CABLE	SAT / CABLE	SAT / CABLE	SOUNDBAR
Curtis 02001	Cogeo Arris DCX-3520 02664	Sagemcom DIW377V 02614	ACER 05891,06051	KONKA 02121,02581	SANSUI 03001,02361	ABOX42 05144,05154	FIRE TV 07254	SLING MEDIA 06644	ANKER 02206
Emerson 03301	COM HEM 05684	Sagemcon DIW3930 05584	AIWA 03381,04871 09071,06151,00591 03381,04611,05231 05164	FRONTIER 02084,02664	SPECTRUM 02084,01294	B&W 00326,00166
FireTV 04441	Contour 03084	Samsung SMT-7100 01364	AIWA (ROKU TV) 03381 02021,02411,03981 09681	ACCESS HD 04194	GENERAL INSTRUMENT (GI) 02084	SUDDEN LINK 02084	BLAUPUNKT 01276
FireTV (Insignia) 04441	Cox Contour 03084	Samsung SMT-7100 01364	AOC 02001,08921 05521	SANSUI (ROKU TV) 03381	ADB 05874,06774	HAUPPAUGE 04684	TELUS 02544,05184	BOSE 00156,01396
..... (or try Dynex codes)	Direct TV 03784	Samsung SMT-7100 01364 09121,03381,03631 09591	SANYO 04011,04021	ADELPHIA 01294,02724	SYSTEMS 02324	TIME WARNER 01294	CAMBRIDGE AUDIO 01056
FireTV (Omni) 02621 03964,03004,04044	Samsung SMT-7100 01364	AOC (ROKU TV) 03381	KTC 02561,04511 01771,03141,03221	AIRTV 06374	HUMAX 02324,03074	TECHNICOLOR 02914	DEFINITIVE TECHNOLOGY 00306,00246
GE Projection 01111	Direct TV (Technicolor) 04154	Samsung SMT-7100 01364	AOC (ROKU TV) 03381	KTV 02561,04511 03381,06351,08431	ALTICE 02084,05504	ILLICO 01294	TECHNOTREND 02814	DENON 00446,00456
Haier 05761	Direct TV (Technicolor) 04154	Samsung SMT-7100 01364	APEX 01391,02981 05191,05391,05521 08711 05514,05524,05534	INSIGNIA 03294,04284	TIVO 02404,02564	EDIFIER 00686,01646
HiSense (Roku) 04154	Direct TV (Technicolor) 04154	Samsung SMT-7100 01364 04521,04631,04731	LG 00201,03381,04641	SANYO (ROKU TV) 03381 05894,06074,06954	IOMEGA 05964,06274	VERIZON 02084,02664	FOCAL 01066
..... 03381,06721	Direct TV (Technicolor) 04154	Samsung SMT-7100 01364 04911,04951,05831	LG (HEALTH CARE) 08711 03381	AMINO 03704,04584	KAON 04254,04264	VENTURER 06694,07414	GOODMANS 00666,00676
Insignia 03961	Direct TV C71KW-400 02324	Samsung SMT-7100 01364 06931	LIQUIDVIDEO 04851	SCEPTRE 02501,02491 06894,07154,07304	KWORLD 07194,07214	VIDEOTRON 01294	HAMA 00656,01896
JVC 03971,06691,02581	Direct TV Genie 02324	SDMC 05594	APEX DIGITAL 01391 09641 09021,05951,09241	APEX DIGITAL 06584	MAGNAVOX 06494,07504	VIEWSONIC 06154	HARMAN/KARDON 00366
..... 01741,01791,06661	Dish 722 02022,04314	SDMC (Android Box) 05044	BANG & OLUFSEN 04551	SEALOC 08461 09411,09441,09481	APPLE TV 05834,07244	MECOOL 05624,05654	WD (WESTERN DIGITAL) 01776,02066	HISENSE 01886
..... 02601,06301,05181 03594,03584,03694,03354	SDMC (Android TV box providers WOW, Teksavvy) 05044	BENQ 06031,05281	SEIKI 02621,08901 09641	ARRIS 02084,02704	MEDIACOM 02764,03084	WOW 05304,08614	JBL 00366,00906
..... 04751 (see article re Dish)	Samsung SMT-7100 01364 05291,05531 09051,06011,06891	SHARP 06621,06721	ASUS 05914	MEDIAISONIC 04864	XBOX 06474,06504	INSIGNIA 00136
JVC Roku 03381	Dish Joey 04314	SDMC 05594	BROKSONIC 02471 06901,08931,09451 09091	AT&T 03004,03224	MEMOREX 06594	XFINITY 03084	JBL 00366,00906
LG 02001	Dish Joey 4 Flipper	SDMC (Android TV box providers WOW, Teksavvy) 05044 04611,05231,09041	SHARP (ROKU TV) 03381	SHARP 06621,06721 03914,06114,06684	METROCAST 03084	XIAOMI 06144	ONN 00576,00706
ONN 06691,03441 does not support	SDMC (Android TV box providers WOW, Teksavvy) 05044 09941	SKYVUE 09091 09131,09141,03381 06754	MIDCONTINENT COMMUNICATIONS 03084	XUMO 05334	ONN (ROKU) 01306
Philips 03801 this RF box	SFR 05594	CENTRIOS 05121	SKYWORTH 02511,04041 05551	BELL 04314,02294,04004	MOTOROLA 00724,02084	ZENITH 02414,02464,02744	ONN 00856,00866,00876
Philips Roku 06691,03381	Dish Joey 4K 02294	SHAW ARRIS DSR800 02344	CETOMER 05871 01401,03431,06531 05551	BOXEE 06364 02414,02464,02744	ZINWELL 02844,04284	ONN 00576,00706
RCA 01721,06651,06641 or 04314	SHAW ARRIS GATEWAY TV BOX 03904 05711	OPTOMA 05631	SHARP (ROKU TV) 03381	BRIGHT HOUSE 01294 02774,03084,03224	ZTE 04834,07364	ONN 00576,00706
..... 05431,03671,03381 (activate IR in box	SHAW ARRIS GATEWAY TV BOX 03904	CURTIS MATHES 02861	PANASONIC 02591	SKYVUE 09091	CABLE ONE 02274 06684,06704,06764	ZUTEST 07054	ONN 00856,00866,00876
..... 06401,04001 menu-settings-remote	SHAW ARRIS GATEWAY TV BOX 03904 03411 08891,03451,08981	ONCOMMAND 05341 02084,02124,05894 07374		ONN 00856,00866,00876
RCA Roku 03381,06641 control-activate IR)	SHAW ARRIS GATEWAY TV BOX 03904	ONN 09341,03381	SONY 00141,08841	ONN 09341,03381 07344	CISCO 01294,02084	MOXI 05024,05034	ONN 00576,00706
Samsung 08821	Dish Wally / Hopper 02294	SHAW ARRIS GATEWAY TV BOX 03904	OPTOMA 05631 06391,03611,09821	ONN 09341,03381 02084,03144,05894 03904	MYGICA 05024,05034	ONN 00576,00706
Sceptre 02491	eStream(Android TV)/ eForce 02564	SHAW ARRIS GATEWAY TV BOX 03904	PANASONIC 02591	SPECTRAVISION 05601	ONN 09341,03381 06074 03904	NETGEAR 05794,05994	ONN 00856,00866,00876
..... 05951,02501,06741 02794,03254	SHAW ARRIS GATEWAY TV BOX 03904 04031	SUNBRITETV 06761	ONN 09341,03381	CHANNEL MASTER 02284	MICCA 06354	OPENBOX 02554,02784	ONN 00856,00866,00876
Sharp 03421	EvoForce 03254	SHAW ARRIS GATEWAY TV BOX 03904	PHILIPS 03801,09301	SUPERSONIC 03621	ONN 09341,03381 03094,04154,06564	MIDCONTINENT COMMUNICATIONS 03084	OPTIMUM 01294,05304	ONN 00856,00866,00876
..... 02851,03861 (see also Evolution)	SHAW ARRIS GATEWAY TV BOX 03904 08901,09031,09321	CHARTER COMMUNICATIONS 03084	ONN 09341,03381	BELL 04314,02294,04004	MOTOROLA 00724,02084	PARADIGM 00586,01126	ONN 00856,00866,00876
Sharp Roku 06601	Evolution / Tivo 02404	SHAW ARRIS GATEWAY TV BOX 03904 02851,08931,01451	CLARO 02274,06384	ONN 09341,03381 02594 02414,02464,02744	PARADIGM 00586,01126	ONN 00856,00866,00876
..... 03381	Fios 02084	SHAW ARRIS GATEWAY TV BOX 03904 03301,03381,03591	COGECO 03084,04154	ONN 09341,03381 05894 06684,06704,06764	PARADIGM 00586,01126	ONN 00856,00866,00876
Sharp Roku 06601	Fision 03224	SHAW ARRIS GATEWAY TV BOX 03904 03921,09811	COMCAST 03084,05814	ONN 09341,03381 05894 07374	PARADIGM 00586,01126	ONN 00856,00866,00876
..... 03381 (old ATT box VIP5662)	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (FIRE TV) 04441 02464,06714	ONN 09341,03381 07554,05934	CISCO 01294,02084	NETGEAR 06044,06064,07444	ONN 00856,00866,00876
Sharp Roku 06601	Evolution / Tivo 02404	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (ROKU TV) 03381	CLARO 02274,06384	ONN 09341,03381 05894 02574,02994,03084	OPENBOX 02554,02784	ONN 00856,00866,00876
..... 03381	Fios 02084	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (XUMO TV) 09811	COGECO 03084,04154	ONN 09341,03381 05894 03914,06544,06714	OPTIMUM 01294,05304	ONN 00856,00866,00876
Sharp Roku 06601	Fision 03224	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (XUMO TV) 09811	COMCAST 03084,05814	ONN 09341,03381 05894 06724,06754,06814	PARADIGM 00586,01126	ONN 00856,00866,00876
..... 03381 (old ATT box VIP5662)	SHAW ARRIS GATEWAY TV BOX 03904	EMERSON 03301,02851 02464,06714	ONN 09341,03381 07554,05934 07044,08604,01274	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Evolution / Tivo 02404	SHAW ARRIS GATEWAY TV BOX 03904 02471,04621,04741	CLARO 02274,06384	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381	Fios 02084	SHAW ARRIS GATEWAY TV BOX 03904 04871,05071,05261,06261	COGECO 03084,04154	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Fision 03224	SHAW ARRIS GATEWAY TV BOX 03904	DYNEX 03961,03001	COMCAST 03084,05814	ONN 09341,03381 05894 07044,08604,01274	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381 (old ATT box VIP5662)	SHAW ARRIS GATEWAY TV BOX 03904 03411 02464,06714	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Evolution / Tivo 02404	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT 02621,04441	CLARO 02274,06384	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381	Fios 02084	SHAW ARRIS GATEWAY TV BOX 03904 08901,09031,09321	COGECO 03084,04154	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Fision 03224	SHAW ARRIS GATEWAY TV BOX 03904 02851,08931,01451	COMCAST 03084,05814	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381 (old ATT box VIP5662)	SHAW ARRIS GATEWAY TV BOX 03904 03301,03381,03591 02464,06714	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Evolution / Tivo 02404	SHAW ARRIS GATEWAY TV BOX 03904 03921,09811	CLARO 02274,06384	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381	Fios 02084	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (FIRE TV) 04441	COGECO 03084,04154	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Fision 03224	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (ROKU TV) 03381	COMCAST 03084,05814	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381 (old ATT box VIP5662)	SHAW ARRIS GATEWAY TV BOX 03904	ELEMENT (XUMO TV) 09811 02464,06714	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Evolution / Tivo 02404	SHAW ARRIS GATEWAY TV BOX 03904	EMERSON 03301,02851	CLARO 02274,06384	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
..... 03381	Fios 02084	SHAW ARRIS GATEWAY TV BOX 03904 02471,04621,04741	COGECO 03084,04154	ONN 09341,03381 05894 02594	PHILIPS 00326,00336	ONN 00856,00866,00876
Sharp Roku 06601	Fision 03224	SHAW ARRIS GATEWAY TV BOX 03904 04871,05071,05261,06261	COMCAST 03084,05814	ONN 09341,03381 05894 02594		